SCCSID = asrinput.man v1.1 02/21/03

Prepared by: Alaa Ali

Date Created: 19 February, 2002 Hydrologic Systems Modeling Division

------

DRAFT								

## SOUTH FLORIDA WATER MANAGEMENT MODEL V5.0 INPUT MAN PAGE FOR

asrinput.dat = Defines ASR System information including Parameters for Canalas, Reservoirs, LOK, and EAA basin runoff as sources and/or destination for ASR. Also, Identifies the grid location of the reservoirs used for injection and/or recovery for ASR. (unit no. 17; read in subroutine sr\_input.F)

\_\_\_\_\_\_

COLUMNS VARIABLE NAME	FORMAT	DESCRIPTION
1. TOTAL NUMBER OF ASR SYSTEMS AND SOME	OPTIONS	FOR THE ESTUARIES
NTOTASR cal_asr_flag stl_asr_flag iuse_asr_envl	Free Free Free Free	Total Number of ASR systems in the model domain.  Flag for Caloosahatchee basin/reservoir(1-ASR exists,0-noASR exists)  Flag for ST Lucie Basin/reservoir(1-ASR exists,0 - no ASR exists)  Option to use ASR to meet Caloosahatchee estuarine requirements  (1-yes,0-no)
iuse_asr_env2  ===================================	Free ======	Option to use ASR to meet St Lucie estuarine requirements (1-yes,0-no)

2 through 10 are repeated NTOTASR times

2. READ the asr capacites (injection and recovery) in MGD and recovery efficiency C factor(a 0.6 factor means 60% recovery, 40% loss), also read minimum bubble C size required for recovery rate can be larger than injection rate.

to exceed injection rate, if desired.	11-20 as: 21-30 as:	r_incap(I) r_outcap(I) reffic(I) in_bubble_sze_add_rec(I)	F10.3 F10.3	ASR Injection capacity(MGD) for System #I ASR Recovery Capacity (MGD) for System #I Recovery efficiency (0.7 means 70% recovery, 30% loss) Minimum bubble size (acre-ft) required before recovery rate is able to exceed injection rate, if desired.
---------------------------------------	------------------------	--	----------------	--

3. FOR SYSTEM # I, NUMBER OF CANAL SOURCES, NAME AND TRIGGER (MINIMUM) STAGE IN EACH CANAL FOR INJECTION INTO ASR. IMPORTANT: FOR CALOOS & STLUCIE ASRS, DEFINE NUMBER OF CANAL SOURCES = 0

1-5	ncnl_src_to_asr(I)	I5, 2X	Number of Canal sources for ASR system #I			
	$nl\_src\_name(J)$		Names for all ncnl_src_to_asr(I) Canal sources.			
	cnl_stg_trig_inj_asr(I,J)	F6.2,2x	Trigger stage for all ncnl_src_to_asr(I) Canal sources.			
		SOURCES,	NAME OF RESERVOIRS, AND ASR CAPACITY FRACTION EACH SOURCE CAN USE FINE NUMBER OF RESERVOIR SOURCES = 0			
1-5	nres_src_to_asr(I)	I5, 2X	Number of reservoir sources for SR system #I			
–	res_src_name(J)		Names for all nres_src_to_asr(I) reservoir sources			
–	frac_cap_src(I,J)		Fraction of total ASR capacity each source can use			
4.1 FOR	SYSTEM #I, READ THIS RECORD ONL	Y IF NUM	BER OF RESERVOIR SOURCES FOR SYSTEM #I IS GREATER THAN 0			
1-6	charid_asr(I,J)	2x, A6	Character id.			
	trig_asr(I,J)	F7.1	Trigger level (ft. NGVD) above which injection to ASR occurs for each reservoir source.			
5. FOR			OURCES AND BASIN NUMBER FOR EACH SOURCE.			
	(1- Miami Canal basin,2-NNRC-HI IMPORTANT: FOR CALOOS & STLUCIE		.,3-WPB Canal basin) EFINE NUMBER OF EAA RUNOFF SOURCES = 0			
1-5	neaa_src_to_asr(I)	I5	Number of EAA basin runoff sources to ASR			
–	eaa_src_num(I,J)	I5	EAA basin number for each of the neaa_src_to_asr(I) sources.			
			(1- Miami Canal basin,2-NNRC-HILL basin,3-WPB Canal basin)			
6. FOR SYSTEM #I, NUMBER OF LOK SOURCES, LAKE ID NUMBER OF EACH SOURCE. (1 - LOK)						
1-5	nlok src to asr(I)	I5	Number of LOK Sources			
	lake_src_num(I,J)	I5	Lake ID Number for each of the nlok_src_to_asr(I) sources.			
7. FOR			AL DESTINATIONS FOR RECOVERY FROM ASR			
			FINE NUMBER OF CANAL DESTINATIONS = 0			
1-5	<pre>ncnl_dest_from_asr(I)</pre>	I5, 2x	Number of Canal destinations for recovery ASR system #I Canal names for all ncnl_dest_from_asr(I) canals			
–	cnl_dest_name(J)	A5, 2x	Canal names for all ncnl_dest_from_asr(I) canals			
7.1 FOR SYSTEM #I, READ THIS RECORD ONLY IF NUMBER OF CANAL DESTINATIONS FOR SYSTEM #I IS GREATER THAN 0 FOR SYSTEM #I, AND DESTINATION #J, NUMBER AND NAMES OF THE CANALS BEING SERVED BY ASR						
1-5	no_cnl_ws(i,j)	I5, 2x	Number of canals served by destination j and ASR i			
	icnl_no_ws_name(k)		Names of each of the no_cnl_ws(i,j) canals			
8. FOR SYSTEM #I, NUMBER AND NAMES OF THE RESERVOIR DESTINATIONS FOR RECOVERY FROM ASR IMPORTANT: FOR CALOOS & STLUCIE ASRS, DEFINE NUMBER OF RESERVOIR DESTINATIONS = 0						
1-5						
1-5 		I5, 2x				

\_\_\_\_\_\_

			BER OF RESERVOIR DESTINATIONS FOR SYSTEM #I IS GREATER THAN 0 AND NAMES OF THE RESERVOIRS BEING SERVED BY ASR				
1-8	charid_asr_rec(i,j)	2x, A6	Character id for destination j				
	trig_asr_rec(I,J,1)	F7.1	Reservoir stage (ft.) below which recovery from ASR is triggered for				
	trig_asr_rec(I,J,2)	F7.1	each reservoir destination. Reservoir stage (ft.) above which recovery from ASR is still allowed for each reservoir destination.				
9. FOR SYSTEM #I, NUMBER OF EAA BASIN RUNOFF DESTINATIONS AND BASIN NUMBER FOR EACH DESTINATION.  (1- Miami Canal basin,2-NNRC-HILL basin,3-WPB Canal basin)  IMPORTANT: FOR CALOOS & STLUCIE ASRS, DEFINE NUMBER OF EAA RUNOFF DESTINATIONS = 0							
1-5	<pre>neaa_dest_from_asr(I) eaa_dest_num(I,J)</pre>	I5 I5	Number of EAA basin runoff destination to ASR EAA basin number for each of the neaa_src_to_asr(I) destinations. (1- Miami Canal basin,2-NNRC-HILL basin,3-WPB Canal basin)				
10. FO	10. FOR SYSTEM #I, NUMBER OF LOK DESTINATIONS, LAKE ID NUMBER OF EACH DESTINATION. (1 - LOK)						
1-5 	<pre>nlok_dest_from_asr(I) lake_dest_num(I,J)</pre>	I5 I5	Number of LOK destinations for system #I  Lake ID Number for each of the nlok_dest_from_asr(I) destinations.				
	11. READ THIS RECORD AS MANY TIMES AS THE TOTAL NUMBER OF RESERVOIRS AVAILABLE FOR ASR INJECTION AND ASR RECOVERY TWO RECORD MAY EXIST FOR ONE RESERVOIR IF IT IS USED FOR INJECTION AS WELL AS FOR RECOVERY						
11.1 READ THIS RECORD IF THE NUMBER OF RESERVOIRS AVAILABLE FOR ASR INJECTION IS GREATER THAN ZERO							
	nnodes_res_to_asr(ia,j)	Free	Number of grid cells for Reservoir ia and ASR # j (we usually have 1 ASR)				
	<pre>icol_asr(ia,j,k)</pre>	Free	Column number of each of the nnodes_res_to_asr(ia,j) cells.				
	irow_asr(ia,j,k) 	Free 	Row number of each of the nnodes_res_to_asr(ia,j) cells.				
11.2 RE	CAD THIS RECORD IF THE NUMBER OF	RESERVOI	RS AVAILABLE FOR ASR RECOVERY IS GREATER THAN ZERO				
	nnodes_res_from_asr(ia,j)	Free	Number of grid cells for Reservoir ia and ASR # j (we usually have 1 ASR)				
	<pre>icol_asr_rec(ia,j,k)</pre>	Free	Column number of each of the nnodes_res_to_asr(ia,j) cells.				
	irow_asr_rec(ia,j,k) 	Free 	Row number of each of the nnodes_res_to_asr(ia,j) cells.				
END OF DESCRIPTION FOR INPUT FILE "asrinput.man"							